

# XR-EM200

## SERVICE MANUAL



Ver 1.1 2003. 06

- XR-EM200 is composed of following models.  
As for the service manual, it is issued for each component model, then, please refer to them.

*US Model  
Canadian Model  
AEP Model  
UK Model  
E Model  
Australian Model*

### COMPONENT MODEL NAME

	XR-EM200
COMPACT DISC DECK RECEIVER SYSTEM	CX-LEM200
SPEAKER SYSTEM	SX-LEM200

### SPECIFICATIONS

Power requirements	120V AC, 60Hz (US,CND,MX,TW) 230V AC, 50/60Hz (AEP,UK) 220-240V AC, 50/60Hz (E51) 220V AC, 60Hz (KR) 220-240V AC, 50/60Hz (SP,MY) 220-240V AC, 50/60Hz (AUS)
Voltage Selector models	110-120V or 220-240V AC, 50/60Hz Adjustable with voltage selector
Power consumption	40W
Power consumption in stanby mode	with ECO mode on: 0.3 W with ECO mode off: 6 W
Dimensions (w/h/d)	Approx. 163 × 230.5 × 243 mm.
Mass	Approx. 3.0 kg
Supplied accessories	FM antenna (1) AM antenna (1) Remote commander (1) Batteries (2)

Specification and external appearance are subject to change without notice.

The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

Les composants identifiés par une marque  $\triangle$  sont critiques pour la sécurité.  
Ne les remplacer que par une pièce portant le numéro spécifié.

### PARTS LIST

Part No.	Description	Remark
ACCESSORIES *****		
1-477-914-11	REMOTE COMMANDER (RM-Z20020)	
1-501-374-92	ANTENNA, LOOP (AM)	
$\triangle$ 1-569-008-32	ADAPTOR, CONVERSION 2P (E51, SP, MY)	
1-754-243-11	ANTENNA (FM)	
1-793-184-21	CONNECTOR (F TYPE ADAPTOR)	
4-247-474-51	MANUAL, INSTRUCTION (KOREAN)(KR)	
4-247-474-61	MANUAL, INSTRUCTION (ENGLISH, TRADITIONAL CHINESE)(TW)	
4-247-474-71	MANUAL, INSTRUCTION (ENGLISH, SPANISH, FRENCH, TRADITIONAL CHINESE)(MY)	
4-247-475-11	MANUAL, INSTRUCTION (ENGLISH, SPANISH, GERMAN, ITALIAN, RUSSIAN, POLISH, HUNGARIAN, CZECH)(AEP)	
4-247-475-21	MANUAL, INSTRUCTION (ENGLISH)(UK)	
4-247-475-31	MANUAL, INSTRUCTION (ENGLISH, SPANISH)(US)	
4-247-475-41	MANUAL, INSTRUCTION (ENGLISH, FRENCH)(CND)	
4-247-475-61	MANUAL, INSTRUCTION (ENGLISH, SPANISH, FRENCH, TRADITIONAL CHINESE)(SP)	
4-247-475-71	MANUAL, INSTRUCTION (ENGLISH)(AUS)	
4-247-475-81	MANUAL, INSTRUCTION (ENGLISH, SPANISH)(E51)	
4-247-475-91	MANUAL, INSTRUCTION (ENGLISH, SPANISH)(MX)	
4-249-131-01	COVER BATTERY (FOR RM-Z20020)	

- Abbreviation  
AUS : Australian model.  
CND : Canadian model.  
E51 : Chilean and Peruvian models.  
KR : Korean model.  
MX : Mexican model.  
MY : Malaysia model.  
SP : Singapore model.  
TW : Taiwan model.

## MICRO HI-FI COMPONENT SYSTEM

9-877-150-02

2003F16-1

© 2003.06

**Sony Corporation**

Home Audio Company

Published by Sony Engineering Corporation

